

SKIP*HOP®

EN

CLEANING & CARE:


Wipe clean with a damp cloth.

MOUNTING INSTRUCTIONS:


***Adult assembly required.**




1. Turn knob counterclockwise to open.



2. Place hub around stroller bar or shopping cart handle so the cup side is vertical. Turn knob clockwise to tighten.



3. Slide cup holder down into slot of hub. Check to make sure hub is secure before placing anything in cup holder.



4. Hub can be mounted on bars at any angle: to adjust angle remove cup, rotate, then re-insert.

⚠ WARNING:

This product is not designed to hold any type of hot beverage. Do not overload. Too much weight may cause stroller to tip. This item is not to be used in playpens, play yards, cribs, bicycles, motor vehicles, or high chairs. This item is for adult use only. Throw away at first sign of damage or weakness. Remove & discard all packaging materials properly.

Maximum weight load: 5 lb

282700-01