


MOONLIGHT & MELODIES hug me projection soother

EN Please retain this information for future reference.

INSTRUCTIONS FOR USE:

Adult assembly required.

3 x AA batteries are included for "try me" (DEMO) mode.
For normal play, move switch to ON.



- Press once for lights only.
- Press again for lights and music.
- Press again to turn off.



LIGHTS: 3 colors cycle automatically: blue - red - yellow

MUSIC: Cycles through 4 songs automatically.

- | | | | |
|------------------|-------------|-------------------|-------------------------------|
| 1 | 2 | 3 | 4 |
| "Brahms Lullaby" | "Für Elise" | "Rock a Bye Baby" | "Twinkle Twinkle Little Star" |


- Auto-off after 20 minutes. Press the button again to desired setting to restart the timer.

TO USE AS A PROJECTOR:

- Flip pocket to the back, exposing projector.
- For best results, project in a dark room onto light-colored wall or ceiling 4-6 feet (1.2-1.8 m) away

TO USE AS NIGHTLIGHT:

- Flip pocket to the front, over belly.
- Lights will have a soft glow.




CLEANING AND CARE:

Spot clean only, air dry.

TO REPLACE BATTERIES (by adult only):

- Flip pocket to the front to cover belly.
- Open hook-and-loop closure.
- Use screwdriver to remove battery door
- Replace with 3 x AA 1.5V batteries.
- Be sure to insert with the correct polarity.
- Replace door and screw closed with screwdriver.



⚠ WARNING:

- Never place product in crib.
- Do Not leave infant unattended with product.
- For use as a huggable nightlight, ages 12 mo.+
- Remove all packaging materials before use.

Do not recharge non-rechargeable batteries. Rechargeable batteries are only to be recharged under adult supervision. Exhausted batteries are to be removed from the toy. The toy is only to be given to a child when fully assembled. Do not short-circuit supply terminals. Rechargeable batteries are to be removed from the toy before being charged. Different types of batteries or new and used/old batteries are not to be mixed. Batteries are to be inserted with the correct polarity. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

CONSUMER INFORMATION: SAFETY AND DISPOSAL

Do not dispose of Waste Electrical Electronic Equipment (WEEE), including batteries, in unsorted municipal waste; collect separately. Dispose of at WEEE collection sites per local regulation. WEEE contains chemicals that are hazardous to the environment and human health. The end-user's participation is critical to the success of WEEE collection.



Do not dispose of WEEE in trash.



© 2016 Skip Hop
50 W 23 ST, NY, NY 10010
In the US: 877.4.SKIPHOP

hello@skiphop.com
www.skiphop.com
Made in China

Meets or exceeds ASTM, EN71 and applicable safety standards.

EC Rep:
Fox Williams
10 Finsbury Square
London EC2A 1AF, UK



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)